



SOKKIA - SETX

Downloading File - USB / CF Card


1. Attach USB or CF card to respective slot.
2. Select **COMMUNICATION (COM)** from the **FUNCTION (FUNC)** menu.




3. Set Data format field to **SDR**, and press **Com (F2)**.



4. Set the configuration as below image, and then press **ENTER**.




5. Press **Send (F3)**, highlight the **Select jobs** then press **ENTER**.



SOKKIA - SETX

6. Uses ◀ / ▶ to change states of job from **No** to **Yes** or select **All (F1)** to select all jobs, then press **ENTER**.



7. Sending status will show on the next page. When completed, press **Ok**.
8. At **Save As**, choose the destination for saving file and press **ENTER**.
9. Enter the file name and click **Ok** or **ENTER**.
10. You will return to the *Communications*.